


# l Inder the Sea Jamboree

#### IO MONTHS +

A solo show of seaside songs straight from the beach

## PLAYING OPTIONS

Press a tentacle to hear that instrument play a tune, press any other to hear a new instrument take over. You can even make a harmony by pressing two tentacles at the same time.



В

Poetic

**TENTACULAR** 

**FUNCTIONS** 

Bubbly

Bubbles

Silly Vocals







## Cleaning Instructions:

- -Surface wash only and let it dry naturally.
- -Make sure to remove the battery pack before washing the octopus as shown in Fig I.
- -Keep the electrical plug dry, do not immerse in water for a long time. Make sure you dry every drop if some water splashes on the plug.
- -Adjust the volume, as shown in Fig 2.

### R FPI ACING BATTER IFS







Fig 2



#### 3 X AAA (I.5V) BATTERIES INCLUDED

- · Do not mix old and new batteries.
- · Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- · Do not throw this product or it's batteries in a fire as batteries may explode or leak.
- · Dead batteries? Check out earth911.com to quickly find the recycling center nearest you.

at mybtous.com. Questions orcomments? Call us (toll-free) at I-866-665-5524

ATTENTION: Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

  Consult the dealer or an experienced radio/TV technician for help.