


- Print in PMS4695 U ■ (SOY-BASED INKS)
- Print MONOTONE High Resolution picture as PMS4695 U
- Print on 128 g 100% Recycled Woodfree Paper
- Don't print dieline & PMS7500 U



7.85" x 5.55"

- Print in PMS4695 U (SOY-BASED INKS)
- Print MONOTONE High Resolution picture as PMS4695 U
- Print on 128 g 100% Recycled Woodfree Paper
- Don't print dieline & PMS7500 U

B.

Poppity
Whale Pop®

9 MONTHS +

Follow up on everything B.
@mybtoys

Crawl over to mybtoys.com and discover an ocean full of wonders. Head popping with questions or comments? Call us (toll-free): 1-866-665-5524

4 AA (1.5V) BATTERIES INCLUDED

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Dead batteries? Check out earth911.com to quickly find the recycling center nearest you.

REPLACING BATTERIES

Rated voltage: 5V
Maximum power input: 5W
Maximum current: 1A

In the unlikely event that a ball gets stuck inside, just flip Poppity upside down and tap gently.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

© 2019 Maison Battat Inc.
B. and Poppity Whale Pop and Just B. Just You. B. You are registered trademarks of Maison Battat Inc.

Manufactured for
Maison Battat Inc.
8440 Darnley Road,
Montreal, P.Q. H4T 1M4
Designed by
Maison Battat Inc.
Consumer Information Line:
1-866-665-5524
Visit us at
www.mybtoys.com

BX1607

100% RECYCLED WOOD-FREE PAPER PRINTED WITH SOY-BASED INKS

7.85" x 5.55"