

B^{baby}

Glowy Chews.
Firely Frank™

3 MONTHS +

Bumpy loops, around a
soothing and glowing lil' bug.


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Replacing batteries



3 x AG9 (LR45 / LR936) BATTERIES INCLUDED


- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Dead batteries? Check out earth911.com to quickly find the recycling center nearest you.

Caution:

Don't immerse to water for cleaning, surface clear only. If water gets inside, remove batteries immediately and dispose them. Dry the toy, then replace new batteries.


ATTENTION: When the module's functions lose performance, follow instructions carefully to install new batteries.

Function



Step 2

Make sure to apply pressure as you secure the cover back into place.



© 2019 Maison Battat Inc.
B. and Glowy Chews and Firely Frank and Just B. Just Y. B. You are trademarks of Maison Battat Inc.

Manufactured for Maison Battat Inc.
8440 Darnley Road,
Montreal, P.Q. H4T 1M4

Designed by
Maison Battat Inc.
Consumer Information Line:
1-866-665-5524

Visit us at
www.mytoys.com

100% RECYCLED
WOOD-FREE PAPER
PRINTED WITH
SOY-BASED INKS



BX1653