


B.



6m+

Twinkle Tummies® Light-Up Plush Panda



Squeeze my belly for a starry glow. See the bees and stars dance to the music as they twinkle...
Magical!



▲
Make sure to position the light-up dome facing upwards.



REPLACING BATTERIES



FUNCTIONS

1. Slide switch to PLAY and press once on the belly to hear 6 soothing songs.
2. Adjust the volume to the desired ambiance. Music plays for 3 minutes.
3. Press once on the tummy or press and hold for a long time to change the song.
4. Press twice quickly, to switch to lights-only. Soothing glow will last 30 seconds.
5. Press on the belly three times to turn the lights and music OFF.

CLEANING INSTRUCTIONS:

Make sure to remove the battery pack before washing your buddy. Machine wash, cold. Tumble dry at a low heat. Do not iron, Do not dry clean, No bleach, Keep away from fire.

ATTENTION: Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

REPLACING BATTERIES

3 AAA (1.5V) BATTERIES INCLUDED

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Dead batteries? Check out earth911.com to quickly find the recycling center nearest you.

BX1744

© 2020 Maison Battat Inc.
B. and Twinkle Tummies and
Just B. Just You. B. You are
trademarks of Maison Battat Inc.

Manufactured for Maison Battat Inc.
8440 Darnley Road,
Montreal, P.Q. H4T 1M4
Designed by Maison Battat Inc.
Consumer Information Line:
1-866-665-5524
Visit us at
www.mybtoys.com
Please remove all packaging
materials before giving to children.

