


# Land of B.

3+

## Lolo's Meowsical Mat Musical Floor Piano

### FUNCTIONS


#### 1 Wacky Sounds

 Dance on the mat to hear wacky sounds!


#### 2 Musical Notes

 Step on the keys to hear piano music!


#### 3 Silly Meows

 Move your feet to hear silly meows!


#### 4 Drum Beats

 **Step 1:** Press the button to hear 1 of 4 drum beats, then switch to the next one by pressing it again.


**Step 2:** Groove to 4 drum beats by mixing in 3 sound effects.



#### 5 Fun Tunes

 **Step 1:** Press the button to hear 1 of 5 fun tunes, then switch to the next one by pressing it again.

**Step 2:** Groove to 5 fun tunes by mixing in the sound effects.




#### 6 Stop Button

Press to stop the dance party. (But why would you?!)




#### 7 Volume Control

Turn it up or keep it down!




#### 8 Piano Keys



LB1893

11.69" x 8.27"



## USAGE GUIDELINES

- Set up this indoor mat on a clean, dry, and flat surface.
- Remove any small items from the play area. No one wants to get an ouchie while they dance!
- Move and groove with no-slip socks or your bare feet, as long as it doesn't feel too slippery.
- Dancing on this mat is a real workout! Remember to hydrate and take a break every 20 minutes or so.
- Store this mat with care and avoid folding it up in four folds.
- Do not place heavy objects on top of the mat, this might hurt Lolo!

## CLEANING RECOMMENDATIONS

Cleaning is easy-peasy! Simply wash the surface of the mat with a damp cloth. If you come across a stubborn stain, chances are it was caused by misuse – so follow the guidelines for mess-free dancing!

## REPLACING BATTERIES

### 3 X AA (1.5V) BATTERIES INCLUDED

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Do not throw this product or it's batteries in a fire as batteries may explode or leak.
- Dead batteries? Check out [earth911.com](http://earth911.com) to quickly find the recycling center nearest you.

**WARNING:**  
  
**CHOKING HAZARD** - Small parts.  
 Not for children under 3 years.

**ATTENTION:** Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



© 2020 Maison Battat Inc.

**Land of B. and Just B. Just You. B. You** are trademarks of Maison Battat Inc. Manufactured for Maison Battat Inc.

8440 Darnley Road,  
 Montreal, P.Q. H4T 1M4

Designed by Maison Battat Inc.

Consumer Information Line:

1-866-665-5524

Colors may vary.

Visit us at [www.mybtoys.com](http://www.mybtoys.com)

Please remove all packaging materials before giving to children.

**LB1893**

11.69" x 8.27"